



91080

## Material

Steel head and fins. Red plastic handle.

## **Technical Notes**

Simplifies insertion and removal of collets in the spindle nose on CNC lathes.


Order No.	Collet size	Fins	$d_1$	$d_2$	$I_1$	l <sub>2</sub>	I <sub>3</sub>	$w_1$	Weight g
91080.W0005	5C	3	31.8	27.9	109.2	12.7	7.6	7.6	159
91080.W0010	16C	3	44.5	27.9	109.2	12.7	7.6	7.6	277
91080.W0015	3J	4	44.5	27.9	109.2	12.7	7.6	7.6	281




# **Collet Stops**



HEX KEYS & WRE



91082



## Material

Aluminium

## **Technical Notes**

Front loading collet stop:
1. Cut stop to desired length.

- 2. Insert stop into collet slots, tighten, face off and deburr.
- 3. Remove and insert machined end into collet. Face off to desired length and deburr.
- 4. Seat into collet and clamp workpiece. Once seated the collet need not be removed for adjustment.

Self-centering and re-usable.

Order No.	Collet size	$I_1$	Weight
			g
91082.W0020	5C	610	168